


1. Please use the grease designated by Trident drive Harmonic Reducer installation note (MF-2 or MF-3)

2. The size with \* in the figure is the reference size for installation, please follow the installation size requirements;

3. For the details of the size, please use the delivery specification drawing to confirm



MODEL	U	T	W
Wave generator-A ø14	ø14H7	16.3 <sup>+0.1</sup>	5P9
Wave generator-A ø19	ø19H7	21.8 <sup>+0.1</sup>	6P9

**NOT FOR PUBLICATION**  
THE REPRODUCTION, DISTRIBUTION AND UTILIZATION OF THIS DOCUMENT AS WELL AS THE COMMUNICATION OF ITS CONTENTS TO OTHERS WITHOUT EXPRESS AUTHORIZATION IS PROHIBITED. OFFENDERS WILL BE HELD LIABLE FOR THE PAYMENT OF DAMAGES. ALL RIGHTS RESERVED IN THE EVENT OF THE GRANT OF A PATENT, UTILITY MODEL OR DESIGN

Title  
**TRIDENT DRIVE HARMONIC REDUCER**  
Part No  
**MSS-32-XX-U-I**  
CAD DRAWN - NOT TO BE MODIFIED BY HAND ALL DIMENSIONS IN MM